

Y20

Body Camera



[User Manual](#)

Index


1. Product Overview	3P
1-1. Package Contents	
1-2. Button Layout	
2. Getting Started	4P
2-1. Charging	
2-2. Memory Card Installation	
2-3. Power On / Off	
3. Video Recording & Flashlight	5P
3-1. Normal Recording	
3-2. Night Vision (Infrared Mode) Recording	
3-3. Flashlight	
4. Audio Recording	5P
4-1. Normal Recording	
5. Snapshot	6P
5-1. Photo Capture	
6. File Review	6P
6-1. Viewing Saved Videos / Audio / Snapshots	
7. Menu	6P ~ 7P
7-1. Sound	
7-2. Video	
7-3. Capture (Snapshot)	
7-4. General Settings	
8. Specifications	7P

1. Product Overview


1-1. Package Contents




Main Unit



Rotating Clip



Vertical & Horizontal
Rotating Clip



USB Type-C
Charging Cable

1-2. Button Layout



1. Video Recording / Flashlight
2. Audio Recording
3. Snapshot
4. Night Vision (Infrared Mode)
5. Flashlight LED
6. Infrared LED
7. Emergency Warning Light
8. Lens
9. Light Sensor

10. Status Indicator
11. Charging Port / SD Card Slot / Reset
12. Emergency Warning Light Indicator
13. Power On / Off
14. Left / Up / Recording List / Zoom Out
15. Menu / Back
16. Right / Down / Previous Video Playback / Zoom In
17. Display

2. Getting Started

2-1. Charging

- Connect the included charging cable to No. 11 (Charging Port).
 - *The power adapter is sold separately, and the device can be used while charging.
 - *Fast chargers are supported. (All chargers and power banks can be used regardless of output.)
 - When connected to a PC, charging and video data transfer can be used simultaneously.
-

2-2. Memory Card Installation

- Insert the SD card into No. 11 (SD Card Slot) as shown in the illustration on the right.
 - *Supports microSD cards up to 512GB.



2-3. Power On / Off

- When the power is off, press and hold No. 13 (Power Button) for approximately 2–3 seconds to turn the device on.
- When the power is on, press and hold No. 13 (Power Button) for approximately 2–3 seconds to turn the device off.

3. Video Recording & Flashlight

3-1. Normal Recording

- When the power is on, briefly press No. 1 (Video Recording) to start recording.
 - *Recording is not available without an SD card inserted.
 - *When recording starts, the status indicator flashes red. The recording icon and recording time are displayed in the upper-right corner of the screen.
 - During recording, briefly press No. 1 (Video Recording) again to stop recording.
 - *When recording stops, the recorded file is automatically saved.
- Tip. While recording or in standby mode, press and hold No. 1 (Video Recording) for 2 seconds to activate Flashlight mode.
- Tip. While recording or in standby mode, use No. 14 (Left) / No. 15 (Right) to zoom in or zoom out.
-

3-2. Night Vision (Infrared Mode) Recording

- While recording in normal mode, briefly press No. 4 (Night Vision) to start night recording.
 - While in night recording mode, briefly press No. 4 (Night Vision) again to stop night recording.
 - *When Night Vision (Infrared Mode) is activated, the screen switches to black and white.
 - *Night Vision can be set to activate automatically based on ambient light. (Refer to 7-4. General Settings.)
-

3-3. Flashlight

- Press and hold No. 1 (Video Recording) to turn the flashlight on.
- Press and hold No. 1 (Video Recording) again to turn the flashlight off.

4. Audio Recording

4-1. Normal Recording

- When the power is on, briefly press No. 2 (Audio Recording) to start recording.
 - *Recording is not available without an SD card inserted.
 - *Recorded files are saved automatically.
- During recording, briefly press No. 2 (Audio Recording) again to stop recording.

5. Snapshot

5-1. Photo Capture

- When the power is on, briefly press No. 3 (Snapshot) to take a photo.

*Shooting is not available without an SD card inserted.

*Captured files are saved automatically.

6. File Review

6-1. Viewing Saved Videos / Audio / Snapshots

- When the power is on, briefly press the lower-left No. 14 (Left) button to view videos, audio recordings, and snapshots.
 - When the power is on, briefly press the lower-right No. 16 (Right) button to play the most recently used file.
- *To go back, press and hold No. 15 (Menu / Back) for approximately 2 seconds.

7. Menu

Tip. When the power is on, briefly press No. 15 (Menu / Back) to enter Menu mode.

Tip. Press and hold the Menu button for 2 seconds to return to the previous screen.

7-1. Sound

- Adjust the microphone sensitivity.
-

7-2. Video

- Configure video recording settings.
(Up to 1296p 30fps)
- Set recording quality.
- Enable pre-recording.
*Video is saved starting from 5 seconds before the record button is pressed.
- Set delayed recording time.
*Recording continues for the set time after stopping the recording.

7-3. Capture (Snapshot)

- Set the snapshot (photo) size.
 - Set the snapshot (photo) self-timer.
 - Set the snapshot (photo) quality.
 - Enable continuous shooting for snapshots (photos).
-

7-4. General Settings

- Set the language.
- Reset settings.
- Adjust the screen brightness.
- Set the date.
- Set Auto Power Off.
*The device powers off during standby.
- Set Screen Saver mode.
*The screen turns off during recording.
- Set the system volume.
- Set Dashcam Mode.
- Set Loop Recording.
*Supported only in Car Mode.
- Set audio recording in Dashcam Mode.
*Supported only in Dashcam Mode.
- Set segmented recording time (for video recording).
- Enable or disable button sounds.
- Set the status indicator.
- Configure Night Vision (Infrared Mode).
- Enable motion detection.
- Set the exposure value (EV).
- Enable voice guidance.
- Set user information.
- Display system information.

8. Specifications

Charging Time	Approx. 4 hours	Voltage	3.7V
Battery Type	Rechargeable Lithium Polymer	Weight	125g
Battery Material	Lithium-ion Polymer	Size	79 x 55 x 24 mm
Battery Model	104050	Recording Time	Approx. 10 hrs
Battery Capacity	2,500 mAh		

Warranty

The warranty period is 1 year from purchase date.

Warranty is based on purchase receipt or purchase record.

Seller 4FACT Co., Ltd.

Address B-1304, 583, Yangcheon-ro, Gangseo-gu, Seoul, Korea

A/S Contact +82-2-6951-4404

