

NT20

Name Tag Body Camera

[User Manual](#)



Index


1. Product Overview	2P
1-1. Package Contents	
1-2. Button Layout	
2. Getting Started	3P
2-1. Charging	
2-2. Power On / Off	
3. Video Recording	4P
3-1. Recording	
4. Audio Recording	4P
4-1. Recording	
5. PC Connection	5P
5-1. Connection	
6. Wi-Fi	5P
6-1. Enable Wi-Fi	
7. APP	6P ~ 7P
7-1. Download APP	
7-2. Connect APP	
7-3. APP Function Settings	
7-4. APP Video Recording	
7-5. APP Audio Recording	
7-6. APP Photo Capture	
7-7. APP File Saving	
7-8. Mark Important Files in APP	
8. Status Indicator	8P
8-1. Indicator Description	
9. Specifications	8P

1. Product Overview

1-1. Package Contents



Main Unit



USB Type-C
Charging Cable



Manual

1-2. Button Layout



1. Charging Port

2. Video Recording / Power On & Off

3. Audio Recording / Power On

4. Lens

2. Getting Started

2-1. Charging

- Connect the included USB Type-C cable to No. 1 (Charging Port).
- When charging while the power is off, the status indicator alternates between mint and blue LEDs for 3 minutes, then switches to a steady blue LED.
- When charging while the power is on, any ongoing video or audio recording will stop. The status indicator alternates between mint and blue LEDs for 3 minutes, then switches to a steady blue LED.
- When charging is complete, the status indicator turns off.

*A 5V 1A low-speed charger is recommended. (If chargers or power banks with mixed outputs such as 9V or 12V are used, fast charging may occur; therefore, use a charger that supplies only 5V.)

*Fast charging may cause malfunction and may void the warranty.

2-2. Power On / Off

- This device can be powered on in two ways:
 - 1) When the power is off, press and hold No. 3 (Audio Recording / Power On) to turn the device on.

*Recording starts automatically when the power is turned on.
 - 2) When the power is off, press and hold No. 2 (Video Recording / Power On & Off) to turn the device on. Press and hold again to turn the power off.

*Recording starts automatically when the power is turned on.
- When the power is on, press and hold No. 2 (Video Recording / Power On & Off) again to turn the device off with a “beep-beep” sound.

3. Video Recording

3-1. Recording

- When the power is off, press and hold No. 2 (Video Recording / Power On & Off) for approximately 5 seconds. The status indicator will flash green, then switch to red with a "beep" sound, and recording will start.
- While recording, briefly press No. 2 (Video Recording / Power On & Off) to stop recording.

*When recording stops, the recorded file is automatically saved.

*After recording stops, the device enters standby mode and the status indicator flashes green.

4. Audio Recording

4-1. Recording

- When the power is off, press and hold No. 3 (Audio Recording / Power On) for approximately 5 seconds. The status indicator will flash green, then stay solid green with a "beep" sound, and audio recording will start.
- While recording, briefly press No. 3 (Audio Recording / Power On) to stop recording.

*When recording stops, the recorded file is automatically saved.

*After recording stops, the device enters standby mode and the status indicator flashes green.

5. PC Connection

5-1. Connection

- Connect the included USB cable to a PC to view, back up, and transfer saved files.
 - *The device has 128GB of built-in memory.
 - *When connected to a PC, the status indicator lights blue.
 - *Disconnecting the device from the PC while files are being transferred may cause file corruption.

6. Wi-Fi

6-1. Enable Wi-Fi

- When the power is off, press and hold No. 3 (Audio Recording / Power On) for approximately 15 seconds to activate Wi-Fi mode.
- When the power is on, press and hold No. 3 (Audio Recording / Power On) for approximately 7 seconds to activate Wi-Fi mode.
- When the red and green LEDs flash alternately, Wi-Fi mode is activated and the device is ready to connect to a smartphone.
- The default Wi-Fi password is "88888888."
 - *When the smartphone connection is successful, the status indicator flashes green.
 - *If the device is not connected to a smartphone within 3 minutes after Wi-Fi activation, it will automatically power off.
 - *For some smartphones, it may be necessary to turn off the "Mobile Data" feature to connect and use Wi-Fi properly.

7. APP

7-1. Download APP



Android



iPhone (iOS)

· Scan the QR code to download the APP.

*You can also search for "4FACT BODYCAM" in the app store to download it.

7-2. Connect APP

- Refer to 6-1. Wi-Fi to connect your smartphone to the device via Wi-Fi.
 - Open the APP and connect to NT20 to operate the device through the APP.
-

7-3. APP Function Settings

- **Recording Resolution** : Set the video recording resolution. (Up to 2304 x 1296 at 30FPS)
- **Loop Recording** : Enable or configure loop recording.
- **Photo Size** : Set the size of snapshot (photo) images.
- **User ID** : Set the device owner number.
- **Device ID** : Set the device's unique identification number.
- **Time Setting** : Set the system date and time.
- **Format** : Format the built-in memory.
- **Factory Reset** : Restore the device to factory default settings.

7. APP

7-4. APP Video Recording

- On the APP's live view screen, select "Record" and tap the icon to start recording.
 - Tap the icon again to stop and save the recorded file.
-

7-5. APP Audio Recording

- On the APP's live view screen, select "Audio" and tap the icon to start recording.
 - Tap the icon again to stop and save the recorded file.
 - *During audio recording, preview mode will be activated.
-

7-6. APP Photo Capture

- On the APP's live view screen, select "Photo" and tap the icon to take a picture.
-

7-7. APP File Saving

- You can download videos and files from the device to your mobile phone via the app.
 - Select the file you want to download and tap the "Download" icon in the app.
 - Once the download is complete, the message "Download Completed!" will appear.
-

7-8. Mark Important Files in APP

- During recording or audio recording, tap the star (★) icon to mark the file as important.

8. Status Indicator

8-1. Indicator Description

- 1) **Power ON / Standby** : Flashing green LED
 - 2) **Recording** : Solid red LED
 - 3) **Audio recording** : Solid green LED
 - 4) **Wi-Fi activated** : Alternating red and green LED
 - 5) **Charging** : Solid blue LED
- *LED turns off when fully charged.
- 6) **Standby (while charging)** : Alternating blue and mint LED
 - 7) **Recording (while charging)** : Solid purple LED
 - 8) **Audio recording (while charging)** : Solid mint LED
 - 9) **Wi-Fi activated (while charging)** : Flashing mint and purple LED

9. Specifications

Voltage	3.7 V	Battery Type	Rechargeable Lithium Polymer
Weight	61g	Battery Material	Lithium-ion Polymer
Size	83 x 32 x 12 mm	Battery Model	803060
Recording Time	Approx. 8.5 hours	Battery Capacity	1,800mAh
Charging Time	Approx. 3 hours		

Warranty

The warranty period is 1 year from purchase date.

Warranty is based on purchase receipt or purchase record.

Seller	4FACT Co., Ltd.
---------------	-----------------

Address	B-1304, 583, Yangcheon-ro, Gangseo-gu, Seoul, Korea
----------------	---

A/S Contact	+82-2-6951-4404
--------------------	-----------------